

## Installation Instructions for the SS49/SS19 Series Analog Position Sensors

ISSUE 4  
PK 88740

### **⚠ WARNING**

#### **PERSONAL INJURY**

- DO NOT USE these products as safety or emergency stop devices, or in any other application where failure of the product could result in personal injury.

**Failure to comply with these instructions could result in death or serious injury.**

#### **SS49/SS19 ELECTRICAL CHARACTERISTICS**

|  |                              |      |      |
|--|------------------------------|------|------|
| Supply Voltage   | 4 to 10 VDC                  |      |      |
| Supply Current   | 4 mA typ.                    |      |      |
| Output Type  | Analog Sourcing              |      |      |
| Output Voltage @ 0 Gauss, 25°C                           | 1.75 to 2.25 V @ 5 V         |      |      |
| Sensitivity (measured between -400 and +400 gauss), mV/G | Min.                         | Typ. | Max. |
|  | 0.60                         | 0.90 | 1.25 |
| Operating Temperature                                    | -40 to +100°C (-40 to 212°F) |      |      |

#### **ABSOLUTE MAXIMUM RATINGS\***

|                     |  |
|---------------------|--|
| Supply Voltage (Vs) | ± 12 VDC   |
| Output Current      | 20 mA  |
| Storage Temperature | -55 to +150°C (-67 to +302°F)                              |
| Magnetic Flux       | No limit. Circuit cannot be damaged by magnetic overdrive. |

\* Absolute maximum ratings are the extreme limits that the device will withstand without damage to the device. However, the electrical and mechanical characteristics are not guaranteed as the maximum limits (above recommended operating conditions) are approached, nor will the device necessarily operate at absolute maximum ratings.

#### **SOLDERING/ASSEMBLY**

##### **SS49**

Support leads during any forming/shearing operation. Do not stress leads inside plastic case.

**Hand soldering** - Use 60/40 rosin core solder, and a 399°C (750°F) controlled temperature, 1/8" chisel tip soldering iron. Do not hold iron on terminals for more than four seconds. Lead temperature at package must not exceed 250°C (482°F).

**Wave soldering** - Use Loncoflux 106A35 or equivalent. Set preheaters at 95°C (200°F) for top (component side) of PC board just prior to entering wave. (This may be adjusted depending upon board thickness.) Set solder temperature at 252°C to 260°C max. (485°F to 500°F). Set conveyor speed to about 4.5 feet per minute (1,37 meter/min.), choosing a speed which gives full solder fillets and minimum bridging and icicles. Provide rigid support for the board.


##### **SS19/SS19T**

Honeywell recommends an infrared reflow process with peak temperatures not to exceed 190 - 200°C (374 - 392°F) for 10 seconds maximum. Keep exposure to high temperatures minimal.


#### **CLEANING**

Clean appropriately in accordance with applicable safety procedures. Honeywell recommends manual cleaning.

#### **BLOCK DIAGRAM**




#### **TRANSFER CHARACTERISTICS**




## TYPICAL OUTPUT CHARACTERISTICS


GRAPH NO. 1 TYPICAL OUTPUT CHARACTERISTICS AT VARIOUS SUPPLY VOLTAGES



GRAPH NO. 2 TYPICAL OUTPUT CHARACTERISTICS AT VARIOUS TEMPERATURES






GRAPH NO. 3 TEST LIMITS





# SS49/SS19 Series

ISSUE 4 PK 88740

## MOUNTING DIMENSIONS (for reference only) SS49 SERIES



## SS19 SERIES



## WARRANTY/REMEDY

Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Contact your local sales office for warranty information. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace without charge those items it finds defective. **The foregoing is Buyer's sole remedy and is in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose.**

Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

For application assistance, current specifications or name of the nearest Authorized Distributor, contact a nearby sales office. Or call:

1-800-537-6945 USA/Canada  
1-815-235-6847 International

## FAX

1-815-235-6545 USA

## INTERNET

[www.honeywell.com/sensing](http://www.honeywell.com/sensing)  
[info.sc@honeywell.com](mailto:info.sc@honeywell.com)

---

**Honeywell**

**Sensing and Control**  
**[www.honeywell.com/sensing](http://www.honeywell.com/sensing)**  
Honeywell  
11 West Spring Street  
Freeport, Illinois 61032