

APPLICATOR PARTS LIST				TYPE LENGTHWISE RING AMPLIYAR			AMP INCORPORATED HARRISBURG, PENNA.				
NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA			TERMINALS
1	WIRE CRIMPER	1	4539256	42				TO APPLY TERMINAL			350571- 640212
2	INS. CRIMPER			43				WIRE SIZE	CRIMP HEIGHT		
3	ANVIL	1	4734056	44				13	.081		
4	ANVIL SPACER			45							
5	SHEAR BLADE	1	44652333	46				12	.086		
6	REAR SHEAR PLATE	1	3850134	47							
7	SHEAR BLADE SPACER	2	4709315	48							
8	FRONT SHEAR PLATE	1	376637	49	HOLD DOWN BLADE MT.	1	811227-2	11	.091		
9	REAR ANVIL SPACER PLT.	1	4708574	50				CRIMP SIZE	TYPE	FEED	
10	FRONT ANVIL SPACER PLT.			51				WIRE	180	F	
11	TOOL SPACER	1	372929	52				INSUL.			.903
12	CRIMP SPACER			53				SLEEVED			
13	FRONT STRIP GUIDE	1	385106-1	54				INSULATION RANGE	WIRE RANGE	MAG	
14	REAR STRIP GUIDE	1	385106-2	55				11-13	11-13		
15	RAM	1	471911	56	FLOATING WIRE STOP ASSY	1	565081-8	EXPLODED VIEW			
16	TOOL HOLDER			57	△ BUSHING	REF	811258-2	A-6000	E 6000-14		
17	ADJ. CRIMP MOUNT			58	△ STOP	REF	811259-2	REMARKS:			
18	ADJ. BLOCK			59	△ SPACER	REF	811260-1				
19	APPLICATOR MOUNT ASSY.	1	570656	60	△ SLIDE	REF	811280-1				
20	BASE PLATE			61	△ MOUNT REAR	REF	811282-1				
21	BASE BLOCK			62							
22	STRIP GUIDE PLATE			63	△ HOLDER - MAGNET	REF	811284-1				
23	ANVIL HOLDER	1	370526	64	△ BRACKET - SLIDE	REF	811285-1				
24	AUX. ANVIL HOLDER	1	377515	65							
25	STRIPPER			66	△ MAGNET	REF	811287-1				
26	STRIPPER MOUNT	REF	811323-1	67	△ WIRE STOP	REF	465344-4				
27	RETAINER PLATE	REF	372251	68							
28	STRIPPER MOUNT BRACKET			69							
29	STRIPPER BUSHING			70	TENSION ADJ. PLATE	1	374999				
30	STOCK DRAG	1	375381	71							
31	STOCK DRAG HANDLE			72							
32	STOCK DRAG STUD	2	354045-1	REV.	REVISION RECORD	DATE	BY	ECN			
33	STOCK DRAG SPRING	2	1-23847-1	A	REV ME BEN	8-22-72	MS	6-9979			
34	STOCK DRAG ADJ. SCREW	2	372997	A1	M/D/O/T/ECN 640212	4-28-71	TM	R1085			
35	FEED FINGER HOLDER			B	ECN A-395892	9-92	MS				
36	FEED FINGER	1	375093								
37	FEED FINGER TIP										
38	FEED FINGER SPACER										
39	BASE CASTING	1	570238								
40	GUARD OSHA	1	457664-2								
41											

DENOTES WEARING PARTS RECOMMEND PURCHASE REPLACEMENT
 THIS APPLICATOR IS TO BE USED ON
 AMP-OLECTRIC 1-471273-3
 MESH FEED
 ALIGN. GA 679597-1
 SERIAL NO. DATE SHIPPED
 CUSTOMER NAME AND ADDRESS
 APPLICATOR NUMBER REV. B 566146-1
 DIST. 4
 DESIGNED
 CHECK'D
 SHEET 1 OF 2

APPLICATOR PARTS LIST (BOLT, NUT, SCREW, WASHER etc.)

NO.	DESCRIPTION	SIZE	LGTH.	REQ.	PART NO.	NO.	DESCRIPTION	SIZE	LGTH.	REQ.	PART NO.
101	SCREW, SOC SET S/L RAM PIN TO RAM (15)	1/4-20	1/2	1	2-21549-3	120	SCREW, SOC. HD. CAP HOLD DOWN (49) TO BLADE (5)	6-32	.300	2	1-811651-1
102	SCREW, HEX. HD. CAP	3/8-16	1 1/4	3	321015-2						
103	WASHER APPL MT. (19) TO BASE CASTING (39)	3/8 I.D.	~	3	371178						
104	SCREW, SOC. HD. CAP	8-32	1/2	3	2-21000-7						
105	WASHER, FLAT STRIP GUIDE (13 & 14) TO APPL. MT. (19)	8 I.D.	~	3	21055-6						
106	SCREW, SOC. HD. CAP	8-32	1/2	1	2-21000-7						
107	WASHER FLAT REAR STRIP GUIDE (14) TO APPL. MT. (19)	8 I.D.	~	1	21055-6						
108	NUT, HEX. DRAG ADJ. SCREW (34)	10-32	~	2	21018-7						
110	NUT, HEX. S/L DRAG (30) SPRINGS (33) TO STUDS (32)	1/4-20	~	2	21022-4						
APPLICATOR ONLY TO INCLUDE											
111	SCREW, SOC. HD. CAP AVI. ANVIL HOLDER (24) (ANVIL (3) TO ANVIL HOLDER (23))	1/4-20	5/8	1	21001-3						
112	SCREW, SOC. HD. CAP ANVIL HOLDER (23) TO APPL. MT. (19)	3/8-16	1 3/4	1	3-21001-8						
113	SCREW, SOC. HD. CAP AVX. ANVIL HOLDER (24) TO APPL. MT. (19)	3/8-16	1 1/2	1	3-21001-7	NOTE: 350571					
115	SCREW, SOC. HD. CAP TOP TOOLING TO RAM (15)	1/4-20	1 1/2	2	21001-8						
116	SCREW, SOC. HD. CAP	8-32	5/16	1	7-21000-4						
117	WASHER, FLAT TENSION ADJ. PLATE (70) TO FEED FINGER (36)	8 I.D.	~	1	21055-6						
118	SCREW, SOC. HD. CAP RET. PL. (28) STRIPPER MT. (26) TO APPL. MT. (19)	10-32	7/8	2	3-21000-8						